

Ai Modules

ConstantWithText

section	Generator
short description	input for a numeric value, can be set by knob, input numerically. or from an external input which can be overwritten
licence level	Anjuna
ports	In Val [control/numeric] Lock to Input [control/numeric] Out Val [control/numeric]
parameter	Value [text/numeric] Knob [rotary knob] Display 8 bit [push button]
skins	Default , 8BitOption, InOutWithOveride

used in example

Plugin Backlinks: Nothing was found.

Manual

Outputs a user defined numeric value. The number value is stored internally as a 64-bit floating point number. It can also be passed through and 'over written' by the control knob. The user can select to display the value as normalised or in 8 bit (0..255).



From:

<https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link:

<https://www.avosupport.de/wiki/ai/modules/controller/constantwithtext?rev=1539791067>

Last update: 2018/10/17 15:44

