

Function

# Dmx.EnableDmxModule

```
Void Dmx.EnableDmxModule(String dfeNodeId, String moduleId, Boolean enable)
```

<b>API</b>	<a href="https://api.avolites.com/12.0/Dmx.EnableDmxModule.html">https://api.avolites.com/12.0/Dmx.EnableDmxModule.html</a>
<b>description</b>	Enables or disables the DMX module.
<b>namespace</b>	Dmx
<b>parameter</b>	dfeNodeId ( <a href="#">String</a> ) : The node identifier. Usually "LocalDevice" for the local outputs.
	moduleId ( <a href="#">String</a> ) : The module identifier. "5" = Art-Net "7" = DMX "10" = sACN
	enable ( <a href="#">Boolean</a> ) : Set to true to enable; false to disable.
<b>return value</b>	<a href="#">Void</a>

## Example in

[Enable/Disable DMX Outputs:](#)

```
<step>Dmx.EnableDmxModule("LocalDevice", "7", true)</step>
```

## Also used in

- [Enable/Disable DMX Outputs](#)

## Remarks

From:  
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://www.avosupport.de/wiki/macros/function/dmx.enabledmxmodule>

Last update: **2020/03/17 02:48**

