

Function

Group.ReplaceGroupOnHandle

Void Group.ReplaceGroupOnHandle(Handle handle)

API	http://api.avolites.com/11.0/Group.ReplaceGroupOnHandle.html
description	Replace a group on a handle, i.e. writes the currently selected fixture into a group on that handle, replacing the old contents.
namespace	Group
parameter	handle (Handle) : the handle to write the group onto
return value	Void

Example in

[Off/On Attribute in Palette:](#)

```
<step>Group.ReplaceGroupOnHandle(userNumber: 999)</step>
```

Also used in

- [Create/Replace Group \(snippet\)](#)
- [Off/On Attribute in Palette](#)

Remarks

From: <https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link: <https://www.avosupport.de/wiki/macros/function/group.replacegrouponhandle?rev=1556952873>

Last update: 2019/05/04 06:54

