# Handles.SapphireWingBBottom.ChangePage

ASSUMPTION

> This function is not documented and simply deducted from other factory macros, and found working. Hence, this entire documentation is assumed.

```
Void Handles.SapphireWingBBottom.ChangePage(int32 index)
```

| | |
|---|---|
| **API** | no |
| **description** | toggles the bottom Playbacks on the second connected Sapphire Touch Faderwing to a specific page |
| **Namespaces** | Handles.SapphireWingBBottom |
| **parameter** | Int32 index – the index of the page to change to |
| **return value** | (Void) |

**Example in**

Pages - Change All Playback Pages:

```
  <macro id="Avolites.Macros.ChangeToPage1" name="Playbacks Page 1">
    <description>Changes the Sapphire Wing playbacks page to page
1.</description>
    <sequence>
       <step>Handles.SapphireWingBBottom.ChangePage(0)</step>
    </sequence>
  </macro>
```

**Also used in**

- Pages - Change All Playback Pages
- Function list

**Remarks**

From:
https://www.avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
**https://www.avosupport.de/wiki/macros/function/handles.sapphirewingbbottom.changepage?rev=1509294949**

Last update: **2017/10/29 16:35**