

Function

Handles.SapphireWingBTop.ChangePage

ASSUMPTION

This function is not documented and simply deducted from other factory macros, and found working. Hence, this entire documentation is assumed.

```
Void Handles.SapphireWingATop.ChangePage(int32 index)
```

API	no
description	toggles the top Playbacks on the second connected Sapphire Touch Faderwing to a specific page
Namespaces	Handles.SapphireWingBTop
parameter	Int32 index - the index of the page to change to
return value	(Void)

Example in

[Pages - Change All Playback Pages:](#)

```
<macro id="Avolites.Macros.ChangeToPage1" name="Playbacks Page 1">  
  <description>Changes the Sapphire Wing playbacks page to page  
1.</description>  
  <sequence>  
    <step>Handles.SapphireWingBTop.ChangePage(0)</step>  
  </sequence>  
</macro>
```

Also used in

- [Pages - Change All Playback Pages](#)
- [Function list](#)

Remarks

From:
<https://avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://avosupport.de/wiki/macros/function/handles.sapphirewingbtop.changepage>

Last update: **2017/11/22 10:01**

