

Handles.SapphireWingBTop.ChangePage

ASSUMPTION

This function is not documented and simply deducted from other factory macros, and found working. Hence, this entire documentation is assumed.

Void Handles.SapphireWingATop.ChangePage(int32 index)

API	no
description	toggles the top Playbacks on the second connected Sapphire Touch Faderwing to a specific page
Namespaces	Handles.SapphireWingBTop
parameter	Int32 index - the index of the page to change to
return value	Void

Example in

[changeplaybackpages](#):

```
<macro id="Avolites.Macros.ChangeToPage1" name="Playbacks Page 1">
  <description>Changes the Sapphire Wing playbacks page to page
1.</description>
  <sequence>
    <step>Handles.SapphireWingBTop.ChangePage(0)</step>
  </sequence>
</macro>
```

Also used in

- [Pages - Change All Playback Pages](#)
- [Function list](#)

Remarks

From: <https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link: <https://www.avosupport.de/wiki/macros/function/handles.sapphirewingbtop.changepage?rev=1509294873>

Last update: 2017/10/29 16:34

