

# Handles.SapphireWingBTop.ChangePage

## ASSUMPTION

This function is not documented and simply deducted from other factory macros, and found working. Hence, this entire documentation is assumed.

```
Void Handles.SapphireWingATop.ChangePage(int32 index)
```

|                     |   |
|---------------------|---|
| <b>API</b>          | no  |
| <b>description</b>  | toggles the top Playbacks on the second connected Sapphire Touch Faderwing to a specific page |
| <b>Namespaces</b>   | <a href="#">Handles.SapphireWingBTop</a>  |
| <b>parameter</b>    | <a href="#">Int32</a> index - the index of the page to change to                              |
| <b>return value</b> | <a href="#">Void</a>  |

## Example in

[changeplaybackpages](#):

```
<macro id="Avolites.Macros.ChangeToPage1" name="Playbacks Page 1">  
  <description>Changes the Sapphire Wing playbacks page to page  
1.</description>  
  <sequence>  
    <step>Handles.SapphireWingBTop.ChangePage(0)</step>  
  </sequence>  
</macro>
```

## Also used in

- [Pages - Change All Playback Pages](#)
- [Function list](#)

## Remarks

From:  
<https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link:  
<https://www.avosupport.de/wiki/macros/function/handles.sapphirewingbtop.changepage?rev=1509294873>

Last update: 2017/10/29 16:34

