

Masters.TapTempo

Void Masters.TapTempo(Handle handle, DateTime panelTimeStamp)

API	http://api.avolites.com/10.1/Masters.TapTempo.html
description	Sets the speed of the master from the tap speed of a key.
namespace	Masters
parameter	handle (handle) : the master handle to apply the tap on
	panelTimeStamp (timestamp) : The panel time stamp. The software then calculates the beat based on the timestamps of the various taps.
return value	Void

Example in

[select_by_titanid](#):

```
<step>Masters.TapTempo(1607, Math.GetCurrentTimeStamp())</step>
```

Also used in

- [Masters - BPM Master \(snippet\)](#)
- [Masters - BPM - Tap](#)
- [Masters - BPM Master - Set Speed](#)
- [Function list](#)
- [Math.GetCurrentTimeStamp](#)
- [Handle](#)

Remarks

From: <https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link: <https://www.avosupport.de/wiki/macros/function/masters.taptempo?rev=1510912721>

Last update: **2017/11/17 09:58**

