Masters.TapTempo

```
Void Masters.TapTempo(Handle handle, DateTime panelTimeStamp)
```

API	http://api.avolites.com/10.1/Masters.TapTempo.html
description	Sets the speed of the master from the tap speed of a key.
namespace	Masters
parameter	handle (handle) : the master handle to apply the tap on
	panelTimeStamp (timestamp) : The panel time stamp. The software then calculates the beat based on the timestamps of the various taps.
return value	Void

Example in

select_by_titanid:

```
  <step>Masters.TapTempo(1607, Math.GetCurrentTimeStamp())</step>
```

Also used in

- Masters - BPM Master (snippet)
- Masters - BPM - Tap
- Masters - BPM Master - Set Speed
- Function list
- Math.GetCurrentTimeStamp
- Handle

Remarks

From:
https://www.avosupport.de/wiki/ - **AVOSUPPORT**

Permanent link:
https://www.avosupport.de/wiki/macros/function/masters.taptempo?rev=1510912721

Last update: **2017/11/17 09:58**