

Function

# SetCurrentMacroFromUserNumber

```
Void UserMacros.SetCurrentMacroFromUserNumber(Int32 userNumber)
```

<b>API</b>	<a href="http://api.avolites.com/10.1/UserMacros.SetCurrentMacroFromUserNumber.html">http://api.avolites.com/10.1/UserMacros.SetCurrentMacroFromUserNumber.html</a>
<b>description</b>	Sets the current macro information from the user number, i.e. flags the macro with this user number as 'current'.
<b>Namespaces</b>	<a href="#">UserMacros</a>
<b>parameter</b>	userNumber ( <a href="#">Int32</a> ) : The user number of the macro to set the current information to.
<b>return value</b>	( <a href="#">Void</a> )

**Example in**

[Macro - Export Macro](#):

```
<step>UserMacros.SetCurrentMacroFromUserNumber(1)</step>
```

**Also used in**

- [Macro - Export Macro](#)
- [Function list](#)

**Remarks**

From:  
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://www.avosupport.de/wiki/macros/function/setcurrentmacrofromusernumber>

Last update: **2017/11/22 10:06**

