

SetCurrentMacroFromUserNumber

```
Void UserMacros.SetCurrentMacroFromUserNumber(Int32 userNumber)
```

API	http://api.avolites.com/10.1/UserMacros.SetCurrentMacroFromUserNumber.html
description	Sets the current macro information from the user number, i.e. flags the macro with this user number as 'current'.
Namespaces	UserMacros
parameter	userNumber (Int32) : The user number of the macro to set the current information to.
return value	(Void)

Example in

exportmacro:

```
<step>UserMacros.SetCurrentMacroFromUserNumber(1)</step>
```

Also used in

- [Macro - Export Macro](#)
- [Function list](#)

Remarks

From:
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://www.avosupport.de/wiki/macros/function/setcurrentmacrofromusernumber?rev=1509294873>

Last update: **2017/10/29 16:34**

