

Function

# System.LockConsole

```
Void System.LockConsole(String lockCode)
```

<b>API</b>	<a href="http://api.avolites.com/10.1/System.LockConsole.html">http://api.avolites.com/10.1/System.LockConsole.html</a>
<b>description</b>	Puts the console in the locked state and sets the current password.
<b>namespace</b>	System
<b>parameter</b>	lockCode( <a href="#">String</a> ) : The code required to unlock the console.
<b>return value</b>	Void

### Example in

[System - Lock Console](#):

```
System.LockConsole("1009")
```

### Also used in

- [System - Lock Console](#)
- [Function list](#)

### Remarks

From:  
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://www.avosupport.de/wiki/macros/function/system.lockconsole>

Last update: **2018/02/17 20:26**

