

Titan Property

# Programmer.CurrentProgrammerIds

<b>API</b>	<a href="https://api.avolites.com/12.0/Programmer.CurrentProgrammerIds.html">https://api.avolites.com/12.0/Programmer.CurrentProgrammerIds.html</a>
<b>description</b>	Gets or sets the current programmer Playback and Cue ID value pair.
<b>Namespaces</b>	Programmer
<b>type</b>	Object

## example

```
<step  
pause="0.001">Programmer.RefireProgrammer(Programmer.CurrentProgrammerIds)</  
step>
```

Here, `Programmer.CurrentProgrammerIds` is passed to `Programmer.RefireProgrammer` in order to restart the shapes currently in the programmer.

## used in

- [Shapes - Reverse, Offset, Restart](#)
- [AcwProgrammerIdPair](#)

From:  
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:  
<https://www.avosupport.de/wiki/macros/property/programmer.currentprogrammerids>

Last update: **2020/03/29 09:16**

