

Titan Property

Programmer.CurrentProgrammerIds

API	https://api.avolites.com/12.0/Programmer.CurrentProgrammerIds.html
description	Gets or sets the current programmer Playback and Cue ID value pair.
Namespaces	Programmer
type	Object

example

```
<step  
pause="0.001">Programmer.RefireProgrammer(Programmer.CurrentProgrammerIds)</  
step>
```

Here, `Programmer.CurrentProgrammerIds` is passed to `Programmer.RefireProgrammer` in order to restart the shapes currently in the programmer.

used in

- [Shapes - Reverse, Offset, Restart](#)
- [AcwProgrammerIdPair](#)

From:

<https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link:

<https://www.avosupport.de/wiki/macros/property/programmer.currentprogrammerids?rev=1585473381>

Last update: 2020/03/29 09:16

