

# Für Sebastian von Jans

## Voline 700W RGB

### DMX Channel Chart

CH	Description	DMX Data	Function
CH1	Laser off	0~41	Switch light of laser
		42~83	Manual control CH2-CH12 valid
	Auto trigger	84~125	Running the built-in animation effects, CH2-CH12 invalid
		126~167	Running the built-in laser beam effects, CH2-CH12 invalid
	Music trigger	168~209	Running the built-in laser beam effects, CH2-CH12 invalid
		210~251	Running the built-in animation effects, CH2-CH12 invalid
		252~255	Manual control CH2-CH12 valid
CH2	Pattern selection	0~255	Pattern selection
CH3	Pattern rotation	0~127	Angle adjustment of pattern rotation for laser
		128~191	Phase reversal rotation speed adjustment
		192~255	Normal phase rotation speed adjustment
CH4	Horizontal rotating of laser pattern	0~127	Horizontal rotating position selection
		128~255	Horizontal rotating speed selection
CH5	Vertical rotating of laser pattern	0~127	Vertical rotating position selection
		128~255	Vertical rotating speed selection
CH6	Horizontal movement of laser pattern	0~127	Horizontal moving position selection
		128~255	Horizontal moving speed selection
CH7	Vertical movement of laser pattern	0~127	Vertical moving position selection
		128~255	Vertical moving speed selection
CH8	Pattern size selection	0~63	Pattern size selection
		64~127	Changing speed selection of pattern from large to small
		128~191	Changing speed selection of pattern from small to large
		192~255	Zoom speed selection
CH9	Pattern gradually changing	0~255	Speed selection of Pattern gradually changing
CH10	Scan speed	0~127	Scan speed selection
	Node effects	128~255	Length adjustment of pattern node
CH11	Color control	0~24	fixed color
		25~199	select single color
		200~224	Effect of changing color
		225~255	Effect of changing color in time
CH12	Adjust the speed of color	0~255	Adjust the speed of changing color from slow to fast

### Maintenance

To prolong the life of the product, it is very important to do maintenance work. The environment is harsh outdoors, or if the product is idle for a long time, damp, smoke or particularly dirty surroundings can cause greater accumulation of dirt on its cover and