

Ai Modules

Ethernet Command


section	Network
short description	takes a text input and sends it to a designated adress as UDP message. Requires a Render Path .
licence level	Bondi
ports	GL Out [GL render] - to be hooked into a render path
	Send Port [numeric/control] - when triggered, the message is sent.
	Msg Port [text] - the actual message
parameter	Port [text/numeric] - the target port
	IP 1 ... IP 4 [text/numeric] - the 4 nibbles of the Ip address
	Message [text area] - input the message here if not fed in the if not fed by the port above
	Send Command [push button] - trigger the send process manually
	Broadcast [toggle button] - whether to send the message as broadcast
skins	./.

used in example

- [Artnet Video Switch](#)

Manual

Sends commands to an external device connected via Ethernet either when loaded or when the Send Command button is pressed.



From:
<https://www.avosupport.de/wiki/> - AVOSUPPORT

Permanent link:
https://www.avosupport.de/wiki/ai/modules/network/ethernet_command?rev=1539772403

Last update: 2018/10/17 10:33

