

Example

MIDI Show Control

by:	Sebastian Beutel, February 2020
published:	here
description:	macros to send some MIDI commands which control MSC-enabled devices/software
remarks:	In order to run this over other ways than real 5pin MIDI Titan v13 is required

[MIDI](#), [MSC](#)

functions

- [Panel.Midi.Send](#)

The complete file with all commands/macros:

[midishowcontrolmacros.xml](#)

Code

[MidiShowControlShortlist.xml](#)

```
<?xml version="1.0" encoding="utf-8"?>
<avolites.macros>

  <!-- MSC Reset -->
  <macro name="MSC Reset" id="Avolites.Macros.MSC.Reset">
    <sequence>
      <step>Panel.Midi.Send("F0 7F 7F 02 01 0A F7")</step>
    </sequence>
  </macro>

  <!-- MSC Go -->
  <macro name="MSC Go" id="Avolites.Macros.MSC.Go">
    <sequence>
      <step>Panel.Midi.Send("F0 7F 7F 02 01 01 F7")</step>
    </sequence>
  </macro>

  <!-- MSC Stop -->
  <macro name="MSC Stop" id="Avolites.Macros.MSC.Stop">
    <sequence>
      <step>Panel.Midi.Send("F0 7F 7F 02 01 02 F7")</step>
    </sequence>
  </macro>
```

```
</avolites.macros>
```

Explanation

This explains the functional steps within the sequence. For all the other XML details please refer to [Formats and syntax](#)

Upon starting such a macro a predefined MIDI command is being sent. For the available commands see <http://www.richmondsounddesign.com/docs/midi-show-control-specification.pdf> however it depends from the device/software which commands are supported.

The Go macro is an example:

- the message F0 7F 7F 02 01 01 F7 comprises of
 - F0 F7 ⇒ Universal Real Time SysEx
 - 7F ⇒ device ID. 7F is all devices
 - 02 ⇒ MIDI machine control command
 - 01 ⇒ command format; 01 = General Lighting
 - 01 ⇒ command (e.g. 01 = Go)
 - F7 ⇒ end of Universal Real Time SysEx message
- When editing know that all data is hexadecimal.
- Additional data (e.g. cue numbers) need to be hex-encoded ascii chars.
 - cue 1 = 31
 - cue 1.5 = 31 2E 35

How to use it

1. [make this macro available](#)
2. for general information about using MIDI to control other devices see [MMC - MIDI Machine Control](#)
3. depending from your setup you might need to use virtual MIDI patchcords like LoopMIDI or rtpMidi, see [Software List](#)
4. sending out MIDI e.g. over USB or network is supported from Titan v13 on

From:
<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:
<https://www.avosupport.de/wiki/macros/example/midishowcontrol?rev=1582205329>

Last update: **2020/02/20 13:28**

