

Web API request

Masters/Flash

Flashes the master to full.

| | |
|------------------|---|
| API | https://api.avolites.com/12.0/Masters.Flash.html |
| namespace | Masters |
| usage | <code>http://[ip]:4430/titan/script/2/Masters/Flash?handle={handle}</code> |
| example | http://localhost:4430/titan/script/2/Masters/Flash?handle_titanId=1605 (link opens in new tab) |
| action | temporarily sets the grand master at 100% |
| parameter | Handle - the master to be flashed |
| returns | nothing if successful error message if request failed |
| remarks | Using a usernumber to identify the master will fail as masters don't have one. Either assign the master to a handle and use its location or use the reserved Titan ID, see titanId |
| | the flashed master must be 'unflashed' from the Web API using Masters/ClearFlash - in order to unflash it on the console do Release Release All Masters, bring the fader up to 100% to level-match, and then lower the fader. |
| | flashing a rate or BPM master results in sending it to the maximum of its range as set in playback options. |

Used In

- [MIDI To Web](#)
- [Web-API requests](#)

From:

<https://www.avosupport.de/wiki/> - **AVOSUPPORT**

Permanent link:

https://www.avosupport.de/wiki/webapi/requests/masters_flash

Last update: **2020/04/19 15:31**

